

Connecting the Wattbike to Zwift Via Bluetooth




wattbike

- d) Navigate through Zwift computer software to the pair devices screen, then press search on all the sensors which you would like to connect to. The WPM will only show in the 'Power Source' and 'Cadence' in Zwift. ANT+* or BLE heart rate sensors can be added at this point. The Wattbike's sensor number is the ID number at the bottom of the WPM screen (also the last 5 digits on the back of the monitor). Once you have selected your sensors, press okay.

*To connect an ANT+ Heart Rate belt insert an ANT+ dongle into your computer.

- e) Ensure your phone is connected to WiFi. If your set up doesn't automatically detect the set up touch the connect to button in the top right hand corner and select your computer-Zwift set up. Once the app is connected to your platform you can now ride.



wattbike



Official Supplier of the UCI World Cycling Centre and its Satellite Centres